



# Instructions

## 1 Million Candle Power Rechargeable Halogen Lamp

Important: Please read these instructions carefully to ensure the safe and effective use of this product.




- Contents/declaration.....1
- Specification/guarantee.....2
- About the torch.....3
- Operation and Use.....4
- Maintenance.....5
- Disposal.....5

Rolson House, London Road, Ruscombe, Twyford Berkshire RG10 9HZ  
 Tel: 0118 940 6500 Fax: 0118 940 6501  
 Email: sales@rolsontools.com

Declare under our sole responsibility that the product:  
 Stock No:- 61785  
 Description:- Rechargeable Torch  
 To which this declaration relates is in conformity with the following directive(s) 2004/108/EC and 2006/95/EC

# Getting To Know Your Halogen Lamp



1. Halogen Light.
2. LED Lights
3. On/Off Switch.
4. Locking Switch.
5. 230V AC Mains Charging Unit.
6. 12V DC Adaptor
7. Halogen/LED Toggle Switch

**UNPACKING:** After removing the packing material, make sure the product is in perfect condition  
The packaging materials (plastic bags, polystyrene, etc.) must be disposed of in an appropriate refuse collection. These materials must not be left within the reach of children as they are potential sources of danger.

## Operation And Use

**Charging AC Or DC (Fig. 1):**  
Will provide approximately 15 mins. of continuous use when fully charged. As the charge diminishes, the light intensity will begin to reduce. The battery will require charging for approximately 20 hours before the first use and should be recharged before the battery is drained completely. Regular charging and discharging will prolong the life of the battery. Before charging ensure the on/off button is in the off position.  
Insert the pin from either the 12V DC charging lead (A) of the 230V AC charging adaptor lead (B) into plug at the rear of the lamp.


- Note: If stored for emergencies, ensure it is fully charged and recharge every four months regardless of use.

- **Spotlight Operation (Fig. 2):**  
To operate the main beam, press trigger (C). For prolonged or hands free operation hold in trigger (C), and lock the switch (D) to the bottom position.

- Note: The torch produces a very powerful, high intensity light. Do not point the spotlight at the eyes.

The spotlight generates heat. Do not touch the lens cover or aim at objects that are very close.

- **LED Light Operation (Fig. 3):**  
To operate the LED light push button (E) which is located at the bottom of the lamp. This toggles between Halogen and LED lights



Stock no.....	61785
Bulbs .....	
Halogen .....	25 W
LED .....	9000-10000 MCD
Battery (sealed lead acid) .....	6V/2.5 AH
Weight .....	0.7kg



Do not dispose of WEEE\* as unsorted municipal waste.



Class II construction (Double insulated).



For indoor use. Do not expose to rain.



Battery must be recycled or disposed of properly. Contains heavy metal - separate collection.

\* Waste Electrical & Electronic Equipment.

- At the end of the working life, ensure that it is disposed of according to national regulations.  
- Contact your local authority for details of collection schemes in your area.  
In all circumstances:

- Do not incinerate.
- Do not abandon in the environment.
- Do not dispose of WEEE\* as unsorted municipal waste.



\* Waste Electrical & Electronic Equipment.